

jkff.xbe

Attributes

```
xbe name=jkff evaluate=yes limit_tstep=yes save_history=yes allow_ssw=no
#
# JK flip-flop
#
Jacobian: variable
input_vars: clk j k
output_vars: q qbar
aux_vars:
iparms:
+ active_pos_edge=1
+ active_neg_edge=0
sparms:
rparms:
+ x_high=1
+ dt=0.1u
+ clk_prev=0
+ j_prev=0
+ k_prev=0
+ q_next=0
+ x_cross=0
stparms: q_st=0
igparms:
outparms: clk j k q
```

Description

jkff.xbe is a JK flip-flop with inputs **j**, **k**, **clk**, and outputs **q**, **qbar**. The start-up parameter **q_st** gives the **q** value in start-up simulation. **clk**, **j**, **k**, **q** are made available as output variables. The parameters have the following meaning.

x_high: high level (in both input and output waveforms).

active_pos_edge: 1 for positive edge triggered operation, 0 otherwise.

active_neg_edge: 1 for negative edge triggered operation, 0 otherwise.

dt: time interval between active edge and change in flip-flop output. It should be smaller than the clock period, say by a factor of 50 or 100.