

s_ammeter_3ph_1 (subcircuit)

Attributes

```
inputs:  
outputs:  
e_left_nodes: pa pb pc  
e_right_nodes: na nb nc  
e_top_nodes:  
e_bottom_nodes:  
b_left_nodes:  
b_right_nodes:  
b_top_nodes:  
b_bottom_nodes:  
parameters:
```

Description

s_ammeter_3ph_1 is used for measuring currents in a 3-phase circuit, which are made available in the form of output variables ia, ib, ic.